Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%



Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%



Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY

Pen Pairing Instructions

1. Switch on Bluetooth on the phone and make sure the device is discoverable.
2. ***Important:*** With PenPusher loaded and in the foreground, tap the pen onto the Pair with Phone pidget to initiate the pen's bluetooth device search mode.
3. If the Pen trys to connect to a different phone, simple push cancel on that device and the pen will continue to search. Repeat as neccessary.
4. Pair the pen with the pairing code and set the connection to Automatic.

☐ Pair with Phone ☐ Clear Pen Memory ☐ Pair with PC

Battery Power Meter

0% 50% 100%

Run the pen from left to right. Where it buzzes indicates the pen battery level

COMPATIBLE WITH ANOTO FUNCTIONALITY